



blaugelb Radio Hand-Held Transmitter

Enables the control of wireless roller shutter motors – conveniently and without cables.

Product features:

The blaugelb Radio Hand-Held Transmitter is the elegant control centre for individual roller shutter motors. Here, the wireless transmitter is taught to the roller shutter motor and, if necessary, the frame of the transmitter is mounted on a wall without having to lay complex cables to the roller shutter motor. The actual blaugelb Radio Hand-Held Transmitter is then held in the holder by a magnet. This has the advantage that the elegant transmitter solution has a fixed place near the respective roller shutter, but free placement of the operating module is possible if required, e.g. on a sideboard or table, and the module can then be returned to its place in the wall bracket after use.

The built-in 1-channel module can control a single wireless blaugelb Roller Shutter Motor or a single created group and is operated in manual mode. The respective operating function is indicated by an LED display and occurs independent of a power source via common AAA batteries.

The blaugelb Radio Hand-Held Transmitter comes with a two-year warranty.

- Elegant control centre as a portable solution with wall bracket
- 1-channel transmitter module
- Simple and quick installation
- Increases the ease of controlling the roller shutter
- Durable and reliable



Technical data:

Nominal voltage:	2 x 1.5 VDC
Transmission frequency:	433.92 MHz
Transmission power:	10 mW
Number of channels:	1
Operating temperature:	-10 °C to +70 °C
Battery type:	AAA
Display:	LED display (function display only)
Fastening:	Wall bracket with screws (2 pcs. 3x16 mm)
Scope of supply:	Radio Hand-Held Transmitter, wall bracket, 2x AAA battery, screws
Dimensions:	143 x 40 x 22 mm

Product name	PU	Item no.
blaugelb Radio Hand-Held Transmitter	1 piece	9084801

Mounting instructions:

Please refer to our blaugelb installation instructions for further information. Further information can also be found in the respective operating instructions for our controllers and their components.